

How to Pack the GoPro Bag:

Packed Case (see next pages)
T. Handheld Extendable Monopod
(Selfie Stick)

R. Head Strap Mount

S. Chest Strap Mount



DO NOT RETURN IN BOOK DROP. MUST RETURN TO CHECK OUT DESK.

How to Pack the GoPro Case:



Pocket Side:

- B. Booklet: "Let's Get Started"
- C. Floating Handle
- D. USB Cable



- P. Flexible Tripod
- O. Tripod Mount
- K. USB Card Reader
- J. Charging Plug
- M. Buckle Mount
- N. Selfie Mount
- Q. J-Hook Mount

Foam Side:

Assembled:

- E. GoPro Camera
- F. SanDisk Memory Card (inside)
- G. Battery (inside)
- H. Frame Mount (around camera)
- I. Thumb Screw

L. SanDisk microSD Adapter

GoPro Parts Guide:



M. Buckle Mount



J. Charging Plug



N. Selfie Mount



K. Hi-Speed SD
USB Card Reader



T. Handheld Extendable
Monopod (Selfie Stick use
w/ Selfie Mount)



B. Booklet: "Let's
Get Started"



O. Tripod
Mount



P. Flexible
Tripod



E. GoPro HERO5
Black Camera



H. Frame Mount
(around camera)



D. USB
Cable

F. SanDisk Micro
Memory Card (inside
camera)



G. Battery for GoPro
(inside camera)



R. Head Strap Mount



Q. J-Hook Buckle Mount
(use with Chest Strap)



S. Chest Strap Mount (use J-Hook
Buckle Mount)



I. Thumb Screw
(holds Frame Mount)



C. Floating Handle